


<b>Car</b>	Mini Cooper S Clubman R55	<b>Part No.</b>	SMN015
<b>Year</b>	2007-2014	<b>Fit Kits</b>	326FK
<b>Notes</b>	Use OE Clamp to fix Scorpion Front Flex to OE	<b>Features</b>	Pipe Diameter:- 63.5mm

Estimated Fitting Time: 1.5 Hours




NO.	PART NO.	DESCRIPTION	QTY
1	762BM	Front Flex Pipe	1
2	755BM	Centre Resonator	1
3	757BM	Link Pipe	1
4	758BM	Y-Piece	1
5	759BM	L/H Rear Silencer	1
6	760BM	R/H Rear Silencer	1
<b>Fit Kit</b>			
7	Z016.10064	63-68mm H/D Clamp	3
8	Z016.10070	65mm H/D Clamp	2

E-MARK	N/A
DATE	13/02/2019
ISSUE	00
AUTHORISED	J.Harkin

- 1) Remove the original heat shield prior to removing the original downpipe.
- 2) Remove the original downpipe retaining all fittings.
- 3) Fit the Scorpion downpipe using the original fittings.
- 4) Once you're happy the downpipe is fitted correctly refit the original heat shield and lambda sensors.

**NOTE:** ENSURE SCORPION SYSTEM IS CLEAR OF MOVING PARTS AND ALL ORIGINAL FUNCTIONS WORK CORRECTLY.



STAY CONNECTED TO RED POWER.